





führen. Auslaufende Batterie-/Akku-Flüssigkeit kann bei Berührung mit Körperteilen zu Verätzungen führen. Bei Kontakt die betroffenen Stellen sofort mit frischem Wasser ausspülen und umgehend Arzt kontaktieren. Anschlussschleppen und Batterien nicht kurzschließen.

▲GEFAHR VOR BRAND UND EXPLOSION

Nicht in der Verpackung benutzen. Produkt nicht abdecken - Brandgefahr. Das Produkt niemals extremen Belastungen wie z.B. extreme Hitze, Kälte, Feuer usw. aussetzen. Nicht im Regen oder Feuchträumen verwenden.

▲ **ALLGEMEINE HINWEISE**

- Nicht verfen oder fallen lassen
- Die LED-Abdeckung ist nicht austauschbar. Bei beschädigter Abdeckung muss das Produkt entsorgt werden.
- Die LED-Lichtquelle ist nicht austauschbar. Wenn die Lebensdauer der LED endet, muss die komplette Leuchte ersetzt werden.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

The light must not be used whilst charging. Fully charge the battery pack before first use.

➤ **INITIAL USE**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

▲ INDICACIONES DE SEGURIDAD GENERALES

Este producto puede ser utilizado por niños a partir de 8 años y por personas con capacidades físicas, sensoriales o mentales reducidas con falta de experiencia si se les informa de su empleo seguro y conocen sus peligros. Los niños no deben jugar con el producto. La limpieza y los cuidados no deben correr a cargo de los niños sin vigilancia.

Mantenga a los niños alejados del producto y de su embalaje. El producto no es un juguete. Los niños deben estar vigilados para garantizarse que no jueguen con el producto o el embalaje.

Evitar las heridas de los ojos; no mirar directamente en el haz de luz ni alumbrar el

rostro de otras personas. Si esto sucediera durante un tiempo excesivo, se podría en peligro la retina por causa de la porción de luz azul.

No tocar nunca un dispositivo conectado a la red de corriente con las manos mojadas o si este hubiera caído al agua. En este caso debe desconectarse primero el seguro o fusible de toda la casa y desconectar seguidamente.

No emplear nunca en entornos susceptibles de explosión, donde se encuentren líquidos inflamables, polvos o gases.

No sumergir el producto nunca en agua u otros líquidos. Todos los objetos iluminados deben encontrarse mínimamente a 15 cm de la lámpara. Emplear el producto sólo con los accesorios que forman

parte del volumen de suministro. No intente nunca abrir una pila o acumulador, aplastarla, calentarla ni quemarla. No arrojar al fuego.

☐ El producto solamente debe cargarse en estancias cerradas, secas, amplias y alejadas de materiales y líquidos inflamables. La no observación puede tener como consecuencia quemaduras e incendios.

Las pilas con fugas o el líquido de los acumuladores pueden causar quemaduras químicas al entrar en contacto con miembros del cuerpo. Al entrar en contacto, enjuagar inmediatamente con agua fresca y ponerse en contacto sin dilación con el médico.

No crear un cortocircuito entre la terminal de conexión y las pilas.

▲ **PERIGO DE INCENDIO E EXPLOSAO**

Não utilizar dentro da embalagem. Não cobrir o produto - Perigo de incêndio.

Nunca sujeitar o produto a sobrecargas extremas, p. ex. calor ou frio extremo, chama, etc. Não utilizar à chuva ou em espaços húmidos.

▲ **INDICAÇÕES GERAIS**


- Não abrir ou desmontar
- As pilas e acumuladores não devem ser expostos a temperaturas superiores a 50 °C
- Não mergulhar o produto em água ou outros líquidos
- Todos os objetos iluminados devem encontrar-se minimamente a 15 cm da lâmpara
- Empregar o produto só com os acessórios que formam parte do volume de sumi-

nistro. Não tente nunca abrir uma pila o acumulador, aplastá-la, calentar-na nem queimá-la. Não a jogar ao fogo.

☐ O produto só pode ser utilizado em locais secos, frescos e afastados de materiais e líquidos inflamáveis. A não observação pode causar queimaduras e incêndios.

As pilas com fugas ou o líquido dos acumuladores podem causar queimaduras químicas ao entrarem em contacto com as partes do corpo. Ao entrar em contacto, lavar imediatamente com água fresca e contactar imediatamente com o médico.

Não criar um curto-circuito entre os bornes de ligação e as pilas.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**

The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



1	2	3	4	5	6	7	8	9	10
1. LED	2. LED	3. LED	4. LED	5. LED	6. LED	7. LED	8. LED	9. LED	10. LED

➤ **INITIATION**

Pressing the On/Off switch cycles through the following functions:

- 1. Low-power cool white LED
- 2. High-power cool white LED
- 3. Warm white LED
- 4. Red LED
- 5. LED flashing
- 6. Off

The red-light function is activated after approximately 3 seconds.

➤ **LIABILITY DISCLAIMER**


The information contained within these operating instructions can be used without proof of liability for direct, indirect, incidental or other damage or consequential damage arising through improper handling or a through disregard of the information contained within these operating instructions.

➤ **WARRANTY INFORMATION**

You are first your warranty terms on www.anmann.de. The guaran-tee does not apply to damage to the device arising through a failure to comply with the operating instructions. Your statutory warranty rights are affected by this.

➤ **CE** The product complies with the requirements from the CE directives.

Subject to technical changes. We assume no liability for printing errors.



heçam os perigos. As crianças não devem brincar com o produto. Os trabalhos de limpeza e de manutenção	Neste caso, primeiro desligar a proteção doméstica e de seguida puxar a ficha de rede. Nunca utilizar em ambientes
--	--

